

# Vertical Moveable Bumper



Insert vertical moveable bumper in between the board slats and onto V-beam. This can be only fitted where there is not a crossmember on the V-beam.



Next rotate bumper upright and swing the bottom arm so it grasps the bottom of the V-beam. Fasten carriage bolt & flange nut.





# Canoe Rack

