






## *Triple Wide Sundeck Instructions*







## View of 2 frames already put together






## ***Leg Spacer & Connecting Pin Already Assembled (reference page only)***





**Leg and decking installed later....**

# Bolt on the 3rd Section

*Bolt on Center Support*



*Bolt on Tie Plates*






## ***Bolt on Leg Gussets and Loosley Fasten U-Bolts***



Tighten 5/16 x 1" Hex Head Bolt, Washer & Nut  
so the Washer Conforms into a Radius as Shown



***Note:***  
***Location of the Gussets***  
***will be marked***



## ***Slide Four Screw Drive Legs through the U-Bolts & Attach the Axle***



***Measure about  
28" - 32"  
from the top  
of the frame  
to the top  
of the leg.***

***Note: longer  
inner legs  
go to the  
lake end  
of the dock***




***Slide axle connection  
into the screw drive legs  
as shown above.***



***Slide the axle connection  
into the leg as shown.  
Tighten the spring bolt  
& lock nut until the threats  
of the bolt just goes beyond  
the lock not leaving  
the spring flexible.***




Insert all the  
Regular Panels  
as Shown




Insert all regular  
panels leave the  
first & last cavities  
open

Pins inserted in  
crossmembers  
as shown



Sundeck End  
Facing Shore



Insert the Starter Panels & Notched Panels as Shown



Screw all 12 Screws to Hold In Notched Panels





Turn clips and tighten to the framework as shown





